

Power Supply Models Pro-Ject Box Program

* **9V/300mA DC - Spare part no**
EU / UK / US: ND-027


Bluetooth Box

Bluetooth Box S

DAC Box S USB

DAC Box S FL

Tuner Box S



9V/2.000mA DC - Spare part no
EU / UK / US: ND-028

CD Box S

Media Box S

Dock Box S Digital

Remote Box S

Stream Box DS

Stream Box DS net



* Wall power supply with low voltage cable

** Power supply with low voltage cable and mains lead

Power Supply Models Pro-Ject Box Program

* **18V/500mA DC - Spare part no**
EU / UK / US: ND-025

Pre Box S

Pre Box DS

Head Box S

Head Box S USB

Dock Box S Fi

DAC Box DS - **until S/N D9268**

Phono Box MM - **from S/N E4360**

Phono Box

Phono Box USB

Phono Box USB V

Phono Box S

Phono Box DS

Phono Box DS+

Speed Box S

Pre Box RS - **until S/N D16272**

* **18V/1.000mA DC - Spare part no**
EU / UK / US: ND-026

Tube Box S

DAC Box DS - **from S/N D9269**


Tube Box DS

CD Box DS

Stream Box DS+

Head Box DS

Speed Box DS



* Wall power supply with low voltage cable

** Power supply with low voltage cable and mains lead

Power Supply Models Pro-Ject Box Program

* $\pm 18V/300mA$ DC - Spare part no
EU / UK / US: **ND-024**

^B Phono Box RS

^B 3-pin mini XLR low voltage plug
(picture)

2x $18V/300mA$ DC - Spare part no
EU / UK / US: **ND-077**

^B Phono Box MM - until S/N E3380
3772 - 4252, 4597 - 4733 and 5098 -
5102. Other S/N with standard 3-
pin low voltage plug

^B 3-pin mini XLR low voltage plug

** $20V/3A$ DC - Spare part no
EU / UK / US: **ND-029**

^A Receiver Box S

^A Stereo Box S

^A Amp Box S

^A Amp Box S Mono - until S/N
C32405

** $20V/3A$ DC - Spare part no
EU / UK / US: **ND-078**

^B Pre Box RS - from S/N D16273

^B Pre Box RS Digital

^B CD Box RS

^B DAC Box RS

^B Head Box RS

^B Stream Box RS

Low voltage plugs are different !

^A coaxial low voltage plug (picture)

^B 3-pin mini XLR low voltage plug



* Wall power supply with low voltage cable

** Power supply with low voltage cable and mains lead


Power Supply Models Pro-Ject Box Program

**** 24V/5A DC - Spare part no**
INT / UK / US: ND-031

Stereo Box DS

Stream Box DSA

Amp Box S Mono - from S/N C32406



**** ±48V/2,5A DC - Spare part no**
EU / UK / US: ND-030

Amp Box DS

Amp Box DS Mono

Stereo Box RS

Amp Box RS

Amp Box RS Mono



* Wall power supply with low voltage cable

** Power supply with low voltage cable and mains lead