



BY PRO-JECT AUDIO SYSTEMS

INSTRUCTIONS FOR USE Pro-Ject CD Box DS2T

Dear music lover,

thank you for purchasing a Pro-Ject Audio Systems CD player.

In order to achieve maximum performance and reliability you should study these instructions for use carefully.



Warning of a hazard for the user, the unit or possible misuse.



Important notice.

Caution! Laser diode, discs to avoid, safety instructions

This product contains a laser diode. To ensure continued safety, do not remove any covers or attempt to gain access to the inside of the product. Refer all servicing to qualified personnel.

If a disc is cracked, chipped, warped, or otherwise damaged, don't risk to play it. You could end up damaging the unit. This player is designed for use with fully circular, full size CDs only. Use of shaped discs is not recommended. The manufacturer and the distributor disclaims all liability arising in connection with the use of damaged or shaped discs.




AC outlet voltages vary from country to country. Before connecting to the mains, make sure that the voltage in your area meets the voltage requirements printed on the power supply.

The power supply is used to disconnect the unit from the mains. Make sure that the power supply is easily accessible at all times. Never handle the device, the power supply while your hands are wet or damp.

Avoid letting liquids enter the device or the power supply. Never place any item containing liquid, such as a flower vase on or near the device. Never spill any liquid on the device or the power supply. Never place any naked flame sources, such as lighted candles on or near the device. The product shall not be used in damp or wet locations, next to a bathtub, sink, swimming pool or any other similar conditions.

Connectors



Make all connections whilst the CD player is disconnected from the power supply. Never use any other power supply than the one supplied with the unit.

Connection to an external D/A-converter

Use one of the available S/PDIF sockets (Coaxial, Optical) or AES/EBU to connect the CD player to a D/A converter or AV processor.

Mains power connection and methods to switch the unit on and off

Connect the low voltage plug from the power supply to the **Power 9V** socket of the unit **before** connecting the power supply to the mains. The unit can be switched on and off by using 2 different methods which are equal in priorities.

1. Using front pushbutton to switch on or into standby

The pushbutton on the front panel of the unit alternately turns the power on or returns it to standby mode. The blue LED on the front panel shows that the unit is powered on. If a trigger signal is present the unit can't be switched off by the pushbutton.


2. Remote power on - triggers

The unit can be switched on via other Box Design components when a 12V trigger voltage is present at the 2.5mm socket marked **Trigger Input**. Special power-on cables (polarity \ominus \oplus) in diverse lengths are available as accessories. The remote power-on signal can be relayed to further units via the **Trigger Output** socket. When the 12V trigger signal is switched off, the unit will also switch off.




Trigger cables may only be plugged into the sockets when the unit is disconnected from the power supply and from the mains. Failure to do so may result in damage of the unit.

Remote control



turns the unit on or back into standby

Volume control



adjust the sound volume of your Pro-Ject Audio amplifier (Excluding Pre box RS Digital, Maia DS(2), Pre Box DS2 Digital, Pre Box DS2 Analogue)

Stop




stops playback

Start / Pause




starts and pauses playback alternately


Selecting tracks




Stepping between tracks, scanning through the disc



Repeat and random play



Front panel controls




Inserting and ejecting a disc

Switch the unit on from standby. Insert the disc into the slot, with the label side facing upwards. The slot-loading mechanism will load the disc automatically. The display shows the total number of tracks on the disc and the total duration of the disc.



Dimming the display



To access that function, playback must be stopped.

Play



Pause



Stop



Stepping between tracks



The display shows the number of the tracks as you step, the elapsed time of the current track and the step icon.

Scanning through the disc



Replacing batteries

Proceed as follows:

- Unlock and slide open the battery case cover
- Replace the battery.
Make sure the battery is the right way round !
- Close the battery case cover

Battery type: 1 x CR2032 / 3V or 1 x CR2025 / 3V



Do not dispose the batteries as ordinary domestic refuse. Please dispose your exhausted batteries at the appropriate collection sites - usually located at supermarkets and drugstores.

Universal-Remote Control-it DS/RS

Control-it DS/RS is optionally available and allows you to comfortably control this and many other Pro-Ject Box Design products on one remote.

Technical specifications Pro-Ject CD Box DS2T

Supports:	Red Book CD-DA		
Digital output:	1 x optical (TOSlink®, S/PDIF) 1 x co-axial (S/PDIF) 1 x AES/EBU		
Trigger input:	12V on/off detector		
Trigger output:	12V		
Outboard power supply:	9V/2.000mA DC; suitable for your country's mains supply		
Power consumption:	300 - 1.500mA DC, <1W in standby		
Replacement battery remote control:	1 x CR2032 / 3V or 1 x CR2025 / 3V		
Dimensions W x H x D (D with sockets):	Aluminium version:	206 x 71 x 199 mm	
	Wood version:	240 x 72 x 199 mm	
Weight:	Aluminium version:	1620 g without power supply	
	Wood version:	2070 g without power supply	

Service

Should you encounter a problem which you are not able to alleviate or identify, please contact your dealer for further advice. Only if the problem cannot be resolved there, the unit should be sent to the responsible distributor in your country.

Warranty



The manufacturer accepts no responsibility for damage caused by not adhering to these instructions for use. Modification or changes to any part of the product by unauthorized persons release the manufacturer from any liability over and above the lawful rights of the customer.

Copyright, trademarks

Pro-Ject Audio Systems is a registered Trademark of H. Lichtenegger.

This guide was produced by: Pro-Ject Audio Systems
Copyright © 2017. All rights reserved.

The information was correct at the time of going to press. The manufacturer reserves the right to make changes to the technical specification without prior notice as deemed necessary to uphold the ongoing process of technical development.

TOSlink® is a registered trademark of Toshiba corporation.